



advanced FLOW engineering™  
 P.O. Box 1719  
 Corona, CA 92878  
 Support: 951-493-7100  
 aFepower.com

## Intercooler Tube Installation Instructions: 2010 Dodge RAM Cummins Intercooler Tube Upgrade L6-6.7L (td)

<b>Kit P/N:</b> 46-20089	<b>Tools Required:</b> 7/16" deep socket 3/16" hex key	<b>Parts list</b> 1 Tube, Upgrade - 05-60048 1 Coupler, hump 3-1/2" - 05-60025 1 Coupler, hump 3" - 05-60012 2 Clamps, spring 3.25" - 03-50530 2 Clamps, spring 3-3/4" - 05-60024 2 Plugs, hex head socket (1/8" NPT) - 03-50029
<b>Make:</b> Dodge		
<b>Model:</b>	<b>Year:</b>	<b>Engine:</b>
Ram 2500	2010	L6-6.7L(td)
Ram 3500	2010	L6-6.7L(td)



Complete Kit



Complete Stock Intercooler tube.



With 7/16" deep socket, loosen clamp on intercooler.



With 7/16" deep socket, loosen clamp on manifold. Push down on intercooler tube and disconnect from manifold. Remove stock intercooler tube from vehicle.



Install plugs in to 1/8" NPT ports with 3/16" hex key.



Install 3" hump coupler with clamps provided to new tube.



Install 3-1/2" hump coupler to manifold with clamps provided.



Install new tube and position into coupler on manifold. Tighten and torque all four clamps to 75 in-lbs. **Check and tighten after 50 miles!** Your Intercooler tube installation is now complete. Thank you for choosing aFe power!

Place the included CARB EO sticker on or near the Intercooler Tube on a smooth, clean surface. EO identification label is required to pass the Smog Check Inspection.