




advanced FLOW engineering™  
 P.O. Box 1719  
 Corona, CA 92879  
 Support: 951-493-7100  
 www.aFepower.com

# BladeRunner™ Charged Air Manifold Installation Instructions: 2003-2007 Dodge Ram Cummins L6-5.9L (td)


<b>Part Number:</b> 46-10011	<b>Tools Required:</b> 11mm socket or wrench 10mm socket or wrench 6mm socket 8mm allen key 5mm allen key 3/16" allen key 6mm hexagonal bit (provided) Gasket remover (scraper) Torque wrench Ratchet w/ extension	<b>Parts list:</b> 1 Manifold, Charged Air 2 Screws, socket cap M8 x 1.25 x 160 2 Screws, socket cap M8 x 1.25 x 100 3 Screws, socket cap M6 x 1 x 8 2 Gasket, manifold 4 Washer, flat M8 1 Washer, fender M6 2 Plug, 3/8" NPT 2 Plug, 1/8" NPT	1 Bracket 1 Tool 6mm, hexagonal bit 1 Threadlocker, blue 2 Badge, aFe Diesel Power
---------------------------------	--	--	---



Step 1  
Stock Intake Manifold.




Step 2  
With a 11mm socket with ratchet, loosen the intercooler coupler hose clamp. With 10mm socket, remove the bolt holding engine oil dipstick.




Step 3  
With 10mm socket and extension, remove the 4 bolts holding the stock manifold. Remove the engine wiring harness connections in back of stock manifold. Pull harness bracket off mounting stud.



Step 4  
Carefully remove stock manifold out of vehicle. ( Place a clean shop rag over air grid heater to prevent anything from entering )



Step 5  
With 10mm wrench, remove the engine wire harness bolt from the back of the stock manifold. Place to the side for later install.



Step 6  
1) Install bracket w/ M6 socket cap screws provided. Torque using 5mm allen key. 2) Install 1/8" NPT plugs to aFe manifold using 3/16" allen key. 3) Install engine wire harness bolt to from step 5 to bracket. (See notes 1, 2 & 3)



Step 7  
Insert the 2 shorter M8 socket cap screws through aFe manifold. Hold washer against inside mounting flange of aFe manifold and feed screw completely through. Insert the two longer M8 screws w/ washers through the outside mounting bosses.



Step 8  
Remove both top and bottom stock gaskets away from air grid heater. Replace with new gaskets provided. ( May require a scraper or scotch brite to clean sealing surfaces. )




Step 9  
Apply threadlocker to the four mounting bolts.




Step 10  
Carefully install aFe manifold into vehicle. Guide bolts through gaskets and air grid heater. Insert aFe manifold into intercooler coupler hose.




Step 11  
With 6mm hexagonal bit provided and 6mm socket, install the four mounting bolts. Do not tighten completely!



Step 12  
Tighten coupler hose clamp with 11mm socket (See notes 2 & 4). Tighten the four mounting bolts from Step 11 (See notes 2 & 5).



Step 13  
Install the two 3/8" NPT plugs to top of aFe manifold. Tighten using 8mm allen key (See notes 1, 2 & 5).



Step 14  
Install the engine oil dipstick using M6 fender washer and socket cap screw provided. Tighten using 5mm allen key (See notes 1, 2 & 3). Attach the engine wire harness to the aFe manifold.




Step 15  
Your installation is now complete. Please check all bolts and screws periodically. Re-tighten if necessary. Thank you for choosing aFe!

Notes: 1) Use provided Threadlocker (P/N 03-50162) on all bolts and screws. 2) DO NOT over-tighten bolts. Please tighten to correct torque spec(s). advanced FLOW engineering™ is not responsible for improper install. 3) Apply 7 N-m (62 in. lbs.) torque. 4) Apply 8 N-m (71 in. lbs.) torque. 5) Apply 24 N-m (18 ft. lbs.) torque.

# DIESEL POWER BADGE

Your system includes one "Diesel Power" logo designed to compliment your truck.  
Use the diagrams below for positioning of the logo for a clean factory look.

## TYPICAL FORD RIGHT FENDER



## TYPICAL RAM RIGHT FENDER



## TYPICAL GM TRUCK LEFT FENDER

